


# WiFi Box

WiFi devices for window actuators control via smartphones and tablets


































#### **ShutterBox**



WiFi device for the control of 230V window actuators via smartphone or tablet.

#### **RwBox**



WiFi device for the connection to wind and rain sensors and control of window actuators connected to the WiFi.

#### InBox



WiFi button for the control of window actuators connected to the WiFi.

#### AirSensor



WiFi detector for measuring the presence of polluting dust and display via smartphone or tablet.

#### **ShutterBoxDC**



WiFi device for the control of 24V window actuators via smartphone or tablet.

### **µRemotePro**



Remote control with rechargeable batteries for the control of window actuators connected to the WiFi.

#### **TempSensor**



WiFi detector, equipped with waterproof measurement probe, for temperature indication and control of window actuators connected to the WiFi, based on detection and temperature changes.

#### WiFi devices for the control of window actuators via smartphones and tablets

8C0470	ShutterBox WiFi device for the control of 230V window actuators via smartphone or tablet.
8C0471	ShutterBoxDC WiFi device for the control of 24V window actuators via smartphone or tablet.
8C0472	RwBox WiFi device for the connection to wind or rain sensors and control of window actuators connected to the WiFi.
8C0480	$\mu Remote Pro$ remote control with rechargeable batteries for the control of window actuators connected to the WiFi.
8C0485	InBox WiFi button for the control of window actuators connected to the WiFi.
8C0474	TempSensor WiFi detector, equipped with waterproof measurement probe, for temperature indication and control of window actuators connected to the WiFi, based on detection and temperature changes.
8C0475	AirSensor WiFi detector for measuring the presence of polluting dust and display via smartphone or tablet.

## Compatible with IOS, Android, Alexa and Google assistant









