


Order designation: 1 set measuring probe



The measuring probe measures and compares the opening needle length and vessel depth in CO₂-bottles


Short description

Comparative measurements must only be performed with the applied CO₂-bottle!

Attention!

Figure 1 a

Figure 1 b




Opening needle in low position (triggered).
Leave the measuring probe for test 2 in this position!

Test 1

Figure 2 a

Figure 2 b



The device must be made operational without the CO₂-bottle (opening needle in upper position ready for triggering).


X-Y = stroke of the opening needle measurable with caliper

For test 3 leave measuring probe in the position as shown in view 2 b!

Test 2

Figure 3 a

Figure 3 b



View 3 b:
When the CO₂-bottle is screwed in the burst disc is perforated by the opening needles.

Test 3

A visual control of the opening needles according to „Test instruction for CO₂-bottles opening needles“ must be performed! →chapter 2, page 33, „Test Instruction for CO₂-Bottles“

Attention!